



TYPICAL CROSS SECTION
FOR SHRUB PLANTING

NOTES

1. SPRAY ALL WEEDS AND UNWANTED PLANT MATERIAL WITH A SUITABLE HERBICIDE TWO WEEKS PRIOR TO WORKS. REPEAT SPRAY MAY BE NECESSARY.
2. CULTIVATE TO A DEPTH OF 200MM.
3. REMOVE ALL RUBBISH AND DELETERIOUS MATERIALS.
4. FOR LARGE BEDS OR AREAS OF HIGH DENSITY PLANTING 'TERRACOTTEM' OR SIMILAR CAN BE APPLIED TO THE SURFACE AT THE RATE OF 150GMS PER SQ.M AND CULTIVATED EVENLY TO A DEPTH OF 200MM.

CITY OF CASEY

SOFT LANDSCAPING
SHRUB PLANTING DETAIL

MANAGER OF ENGINEERING &
ENVIRONMENTAL SERVICES
LAST UPDATE 09.11.2012

AMENDMENTS:

S-1005